

## SUPPO™ Speed Controller Programming Instructions

For ESC with simple options (With Heli-functions)

20A/30A/40A -Heli

Programming Instructions:

1. Connect your motor and receiver to the speed controller, but do not connect the battery yet.
2. Turn on your transmitter and full up the throttle stick. Please Note: Most Futaba transmitters have the throttle channel reversed by default.
3. Connect your battery and you will hear a starting beep tone. After 3 seconds, the controller will start beeping a sequence as following. All beeps only repeat once.
4. To select, move the throttle stick in off position, between Beeps repeat. Then you will hear a confirmation sound.
5. Each time when you select an option, it will exit programming menu and is ready to use. To choose another option, you need restart from step 1.

Options Table , ESC for Helicopter with Simple options

	Beeping (with 0.5s break)	Options (one option selected, others will be disable )
1	—, —	Normal (Disable Governor Mode) * (default)
2	— —, — —	Governor Mode with 2-4 poles motors
3	— — — —, — — — —,	Governor Mode with 6-10 poles motors
4	— — — — —, — — — — —,	Governor Mode with 12-14 poles motors